


## Aluminum Alloy Trim Tab Kits (Control Switch Not Included)

Lectrotab Kit without Control Switch	Kit Contains these Parts
XKA9X9A	2 – Actuators with 23’ (7m) cable  2 – Marine Grade Aluminum Alloy Tabs  
XKA9X12A	
XKA9X18A	
XKA9X24A	
XKA9X30A	
XKA9X36A	
XKA12X9A	
XKA12X12A	
XKA12X18A	
XKA12X24A	
XKA12X30A	
XKA12X36A	
XKA12X42A	

## Aluminum Alloy Trim Tab Kit Model Number

<b>XK</b>	<b>A</b>	—	<b>12</b>	<b>X</b>	<b>12</b>	<b>A</b>
XK = 23’ (7m) Actuator Cable K = 6’ (1.8m) Actuator Cable		No Designation = No Control Switch Included	1st Number = Tab Chord Length (inches)		2nd Number = Tab Width Across Transom (inches)	A = Aluminum Alloy Tabs
<b>A</b> = Standard Actuator 12vdc, 2.25” (57mm) stroke, 8 second stroke time <b>B</b> = Standard Actuator 24vdc, 2.25” (57mm) stroke, 8 second stroke time <b>S</b> = Short Actuator 12vdc, 1.50” (38mm) stroke, 6 second stroke time <b>C &amp; D</b> = See Note Below						

**Note:**

Actuators are also available with a 4 second stroke time. 4 second stroke time model numbers begin with the letter “C” for 12vdc and “D” for 24vdc.

Please note that Lectrotab recommends using the 8 second stroke time for a smoother, more controlled boat response to tab adjustments.